

Objective: This week's issue will cover the following subject.


- 🔴 Priming of the ink Lines

Benefits:

- 🔴 New Software (ver 3.49 and later) allows you to prime 1 valve at a time. The previous version of software only allowed you to prime all valves
- 🔴 You may prime 1 to 4 valves as needed.

Procedure to prime ink lines:

1. Log in as a technician using code 741963
2. At the ink Center tab, select one of the ink droplets at bottom center.
3. Select the valve(s) you need to prime (black was selected as an example)
4. Select "Start Prime"
5. When complete select "Priming Complete"
6. Touch any gray are of the screen to return to ink Center.



costco-signalhill:0.0

Disconnect Options Clipboard

STEPS 3 and 4

ink center maintenance system contact help Tech Pane

Ink Nests Below - Choose one

SELECT CARTRIDGE to start

Fill chamber ready

Prep A

12 13 14 15 16 23 24 25 26 27 33 34 35 36 37 43 44 45 46 47

Current unfillable cartridges

Black Yellow Magenta Cyan Start Prime

Separator LOG OUT

After selecting color(s) you want to prime, select "Start Prime"

ris-training4:0.0

Disconnect Options Clipboard Record Send

Step 5

ink center mantenimiento sistema contacto ayuda panel técnico


Priming All Inks

Rinse Vacuum Dispense

Ink 1 Ink 2 Ink 3 Ink 4 Inks 5/6

Select Priming Complete

Priming Complete



Contact Information For service related support, please call RIS @ 1-858-779-9148 Option 3

The location of the "Top 10 Issues" platform has changed. Please bookmark the following URL for easy access – <http://training.retailinkjet.com/top10/>